

INDOT Consultant New User Quick Start Guide

**ProjectWise (Thick Client and Web Server), ITAP, DOTWise
Project Creator, Connection Information**

12/14/2016
State of Indiana
INDOT CAD Support

Contents

1.	Welcome to INDOT CAD	5
2.	Requesting ProjectWise Access and the DOTWise Project Creator	7
2.1	Business and User Enrollment in ITAP.....	7
2.2	Requesting Access ProjectWise and the DOTWise Project Creator	8
3.	ProjectWise at INDOT	13
3.1	Creating ProjectWise Folders Using the Project Creator	13
3.2	Using the ProjectWise Web Server.....	16
3.2-1	Changing your Password	19
3.3	Using the ProjectWise Explorer Client.....	20
3.3-1	ProjectWise Explorer Client Connection Settings.....	21
3.3-2	ProjectWise First Connection	22
3.3-3	Changing Your Password	24
3.4	INDOT ProjectWise Basics	25
3.4-1	ProjectWise Folder Layout	25
3.4-2	Consultant Folder Structure	26
3.4-3	ProjectWise Security	26
4.	CAD Support and Documentation Resources	29
4.1	INDOT CAD Website	29
4.2	DOTWise	29
4.3	ProjectWise Documents Folder	30
4.4	Bentley User Community	30
4.5	Signing up for Gov Delivery and CAD Emails.....	30
4.6	Contacting INDOT CAD Support.....	30

1. Welcome to INDOT CAD

A Message from CAD Support

What you need to know

The purpose of this document is to quickly get you started on the right road at INDOT in terms of your firm doing business with INDOT. This document is what we call a quick start guide and will contain how- to's on everything from ITAP (creating an account and requesting access to a new application) to creating a Consultant Folder in ProjectWise. Anyone wishing to use/access INDOT's ProjectWise datasource must enroll via ITAP. This document will also discuss what ProjectWise is and how to navigate within it and also the IN.gov site (related to CAD) and GovDelivery subscriptions (important notifications about CAD software).

Thanks,

Jason Kuhn

Kennedy Huynh


2. Requesting ProjectWise Access and the DOTWise Project Creator

Usage of INDOT's ProjectWise system is rapidly becoming a normal means for INDOT users and consultants to share data, or for consultants to work out of to take advantage of our managed workspace configuration. This chapter will look at the steps necessary for a consultant to (1) get their firm access to the INDOT Technical Applications Pathway (ITAP) (2) individual users request an ITAP account (3) users enrolling for INDOT ProjectWise (DOTWise) access and to our Project Creator system.

2.1 Business and User Enrollment in ITAP


In order to request access to a number of INDOT systems including ProjectWise, and the ProjectWise Project Creator, all firms and required users will need to be enrolled via the INDOT ITAP system. Instruction for enrolling business and users in ITAP can be found on the ITAP homepage at <https://itap.indot.in.gov/>.

Each particular workflow can be found in the ITAP help link at the top of the page or via one of the videos under the ITAP Training Videos header on the lower right:



ITAP Help Resources

Should you require assistance working with ITAP, you can submit a help desk ticket directly to the support staff via the Contact ITAP Support link at the top of the page.




Contact ITAP Support

2.2 Requesting Access ProjectWise and the DOTWise Project Creator

With your firm and users enrolled for ITAP access, users may now begin the process to enroll for ProjectWise access. Previously requesting access to this was separate to the Project Creator, but these functions have been combined into a single access request. The following steps illustrate the end user process for requesting and receiving access.


To request access to ProjectWise and the DOTWise Project Creator you will start out by going to the following location:

1. A User may request access to a new INDOT application from the ITAP Menu and from the ITAP Home Page.
 - a. Option #1 -To request a new application from the ITAP Menu, select Application, and then Request New Application.




Request New Application

- b. Option #2-To request a new application from the ITAP Home Page, click on the link “Click here to request access to new application”.




Request New Application

2. Selecting Request New Application from the ITAP Menu or the link “Click here to request access to new application” from the ITAP Home Page will display the Application Enrollment panel.



Application Enrollment

3. In the Application Enrollment panel, select one of the ProjectWise entry, followed by the DOTWise listing underneath it from the left side of the panel. Application Details and Available Roles (if applicable) will be displayed on the right side of the Application Enrollment panel.



DOTWise Application Enrollment


Note: Roles are for internal use only and will have no affect when selected by external users. External users will have their roles configured specific to their firm.

4. To complete the application enrollment, select the Submit button on the bottom of the right hand panel.
5. If the Submit was successful the Message below displays, click on the OK button.




Successful Request

6. If your account already has a pending request for the application, you'll receive the following message. Select OK to continue, this indicates that a request is currently outstanding and awaiting additional input.



Pending Request

Once the request has been completed, you will receive an email with a recap of what has been requested. In addition to this information, it will also contain the name of the business administrator responsible for approving the next step in the process.



Request Acknowledgement

Note: INDOT CAD Support acts on account requests in the order we receive them, normally in 1 business day. For external users, please note that all requests must go through your firm's business administrator for approval. If you do not receive a timely response to your account request, please contact indotcadsupport@indot.in.gov and we can provide the name of your business administrator. Please keep in mind however, we cannot circumvent the approval process.

Upon approval of the application enrollment, two emails will be received. First will be an automated email from the ITAP system stating that approval has been granted to the application. The second

email in most cases will be a confirmation from the INDOT CAD Support staff with relevant information including username and password information for the INDOT ProjectWise system. ***Note that the password for the INDOT ProjectWise system will be different from the one used to access the ITAP system.***

3. **ProjectWise at INDOT**

ProjectWise is a suite of software provided by Bentley Systems aimed at helping to manage, find, and share active project data; including CAD and geospatial content, as well as Office documents.

Standard Key Benefits

- Save time finding, validating and accessing project information
- Reduce project risk with a single source of truth for all project information
- Improve quality and consistency of all project deliverables
- Meet deadlines
- Share work across multiple offices and locations
- Access to INDOT's Managed Workspace

Key Benefits for Consultants working on INDOT Projects

- The sharing of Data with INDOT staff
- No more using of FTP sites to transfer data
- No more burning of data to CD's
- No need to mail CD's or physically carry CD's of data to INDOT
- No more attempting to attach large files to emails and hoping they get there when you send them
- Quick visual confirmation that the data is in the folder (audit trail)
- Work on projects in different Districts and see them in one screen using ProjectWise

INDOT has positioned ProjectWise as their active project storage system for CAD and other associated project data. However it is not a replacement for ERMS and any data upload requirements that are otherwise specified for the agency. From the consultant standpoint, INDOT's ProjectWise system can be a convenient way to share and collaborate on data in a single system directly with INDOT personnel.

3.1 Creating ProjectWise Folders Using the Project Creator

To maintain a consistent folder structure and security model for each project, and prevent unnecessary loss of data; all top level folder structures (discipline level, consultant folders) are created using our on-demand folder creation tool. As part of the initial user access request via ITAP that was discussed in the previous section, access to this tool is also granted.


Note that only top level folders are created using this tool such as those folders for the designation number, discipline folders (ex. Design, Environmental Services), and consultant folders (ex. Design Firm A Inc., Survey Firm B LLC). Subfolders may be created underneath these folders as long as a user has the appropriate permissions for these folders.

Creating a Project/Folders

Most currently active INDOT projects should already have a ProjectWise folder structure. Depending on the state that the project is at it could have as few as one discipline, or a number of different discipline folders. Being on demand, folders are only created when necessary eliminating additional project clutter where possible. Please keep in mind that it's entirely possible that the Designation Number may not exist, but as part of the project creation tool, will be created.

To create your consultant project folder:

1. Log in to ITAP (<https://itap.indot.in.gov/login.aspx>), and locate the ProjectWise entry under INDOT Applications. Expand this entry and select DOTWise. Select the “Click here to access application” link.



Accessing the DOTWise Project Creator

2. Once in the Project Creator you will be prompted to enter the information for your project. The first piece of required information is the Designation Number. Enter the number for your project and select “Click her to validate the entered Des Number” field.

DOTWise Project Creator

Screen Mode: **ADD**

Enter Des Number: 10064

Click here to validate the entered Des Number

Project District Location

Project Route Number

Create Project Clear

* This color background fields are mandatory

Des Number entry and Validation

- Depending on the information entered for the Des Number, you will receive either an error that the Des Number isn't valid requiring the entry to be rechecked, or that it's valid and the project creator can continue.

Note that the Project Creator validates on data from other INDOT systems. Due to the method used to sync this data across these systems there may be a 24 to 48 hour lag between when a Des Number is created and when it can be created in ProjectWise. If a project is needed immediately, please contact indotcadsupport@indot.in.gov

- With a validated Des Number, the project creator will activate the "Create Project" button with a brief overview of the Des Number, District Location, and Route Number. Create the project to proceed.

DOTWise Project Creator

Screen Mode: **ADD**

Enter Des Number: 1006465

Click here to validate the entered Des Number

Project District Location: Seymour


Project Route Number: SR 56

Create Project Clear

* This color background fields are mandatory

Create Project

5. Upon selecting the “Create Project” button, your project will be queued in the project creator to be placed into ProjectWise. In most cases this is instantaneous, should your project not be created after 15-20 minutes, please contact the CAD Support staff so we can investigate. You will receive a heads up notification with the information on your project.




Project Created

With your project created you may either proceed to create additional project structures or exit the tool and proceed to working in ProjectWise through one of the two methods described in the following sections.

3.2 Using the ProjectWise Web Server

INDOT provides two ways to connect to the ProjectWise environment. The first option that we'll investigate is the ProjectWise Web Server. This is a lightweight web site that can be accessed in a number of web browsers, but works best when using Internet Explorer versions 8 thru 11. No administrative privileges are required to connect to the web server. To connect to the ProjectWise Web Server:

1. Navigate to <http://www.in.gov/indot/3116.htm> in your web browser of choice.
2. If using Internet Explorer, consider installing the ActiveX Controls from the Downloads section. These allow for basic DGN file previewing and limited drag and drop functionality within the Web Server.



ProjectWise Web Server Downloads

3. Access the ProjectWise Web Server through the DOTWise Web Server link, or going to <https://dotwise.indot.in.gov/login.aspx>.

ProjectWise® Web Server

Location
<none>

[Sign in using your Windows credentials](#)

User Name

Password

Log in

ProjectWise Web Server

4. From the Location dropdown, select the DOTWise entry. Enter your username and password for their respective fields. Complete signing in by selecting Log in.

ProjectWise® Web Server

Location
DOTWise 1

[Sign in using your Windows credentials](#)


User Name
@company-a.com 2

Password
..... 3

Log in

Login Screen

5. You will then be placed into the ProjectWise Web Server.



ProjectWise Web Server


While fundamentally the same as the desktop Explorer client, there are some important differences between the two versions:

- There is no direct application integration and applications will not launch from this connection.
- The managed workspace is not available.
- There are restrictions on the number of items displayed at a given time, and the system reverts to using page selection.
- Certain areas have multi-file functionality omissions.

The Web server however is ideal for quickly uploading and downloading data that will not be worked on out of ProjectWise.

Getting Help on the ProjectWise Web Server

For those already familiar with the ProjectWise Explorer client, the basics of operation for the web server are similar. For more specific on web site functionality and usage, please review the on-line help under the Help > Content menu option.




Online Help

3.2-1 Changing your Password


To change your ProjectWise password via the ProjectWise Web Server:

1. Make sure you're logged into the webserver as shown in the previous section.
2. From the Web Server toolbar, select Tools > Change Password.




Change Password

3. On the Change Password window that pops up, enter your current password (1) along with your new password (2) and your new password a second time (3) to confirm.

A dialog box titled "Change Password" with a close button (X) in the top right corner. It contains three input fields. The first field is labeled "Current password" and has a red arrow pointing to it with the number "1". The second field is labeled "New password" and has a red arrow pointing to it with the number "2". The third field is labeled "Repeat new password" and has a red arrow pointing to it with the number "3". At the bottom of the dialog box are two buttons: "OK" (green) and "Cancel" (red).

Change Password

4. When complete, you'll receive the following confirmation that your password change is complete.



Password Change Complete

3.3 Using the ProjectWise Explorer Client

The most common connectivity method for ProjectWise is the ProjectWise Explorer "Thick" client which can be acquired and installed on end user PCs. For more information on the ProjectWise client software, please refer to the [Bentley Product Page](#).

Advantages of using the ProjectWise Explorer desktop client are as follows:


- Windows Explorer-like functionality
- Drag and Drop within the system and from the Desktop PC

- Direct MicroStation integration and access to the INDOT managed workspace for direct delivery of CAD resources
- Office Application Integration for Open/Save/Save As functionality

Currently INDOT is operating on ProjectWise SS4 Servers which allows for client users to use any version of ProjectWise Explorer from V8i up through all SELECTSeries releases and through the current Connect releases. This ensures a wide range of compatible versions and should be able to accommodate those consultants who may be on other versions of the client software.


3.3-1 ProjectWise Explorer Client Connection Settings

To configure your ProjectWise client to connect to INDOT's ProjectWise system please enter the following settings in your ProjectWise Network Control Panel applet. It is highly recommended that these settings be configured by a user with administrative rights or the appropriate IT staff.




Control Panel/ProjectWise Network

Under the DNS Services provide the INDOT Server with a name such as the one shown, or easily identifiable by support staff. The hostname and port settings should be set to dotwise.indot.in.gov and 5800 respectively.



DNS Services Settings

On the Datasource Listing tab, again enter a name easily identifiable and the hostname and port to dotwise.indot.in.gov and 5800. When ready, select OK or Apply to save your settings.




Datasource Listing

With these settings entered alongside any additional ProjectWise connections, you can then launch the ProjectWise Explorer software and login to the DOTWise datasource.

3.3-2 ProjectWise First Connection

With ProjectWise now configured, you can enter the software and connect to the INDOT DOTWise datasource. In your datasource tree you'll see a new entry for DOTWise in the left hand panel. Left click on the plus [+] symbol to initiate the login prompt.




Logging into DOTWise

As part of your initial request to the ProjectWise/DOTWise application in ITAP, you will have received a username and password to the INDOT ProjectWise system. Enter this information to login for the first time. Please note that the Use Windows Single Sign-On check box should remain blank.

Note that the login information for ProjectWise is not the same as your ITAP credentials and they are not connected. Additionally, INDOT CAD Support has standardized on email address usernames for external clients. Should you receive any login errors prior to creating a working directory, please contact the INDOT CAD Support staff so your account can be adjusted.

During the initial login, ProjectWise will prompt for the creation of a working directory and defining this location is required for ProjectWise connectivity. This location is where ProjectWise stores data locally while you are working with it. Please create/select a location on your PC where this data can be stored while it's being worked on. This prompt will only appear during this initial login, and if the end user receives a new PC or has their operating system reinstalled. Subsequent logins by the same user on the same device will not display this prompt.



Locating/Creating a Working Directory

It's highly advised that users not directly access the contents of their working directory. When needing to clean the contents of this location, users should use the Local Document Organizer tool within ProjectWise Explorer. This location should only be interacted with under the supervision of a ProjectWise Administrator.


With the initial connection completed, you may now begin to working within the INDOT ProjectWise system.

3.3-3 Changing Your Password

As part of the initial email with your account information and password, INDOT CAD Support highly recommends that you change your password after the first login. As always, good and secure passwords:


1. Use a unique password for each of your important accounts.
2. Use a mix of letters, numbers, and symbols in your password.
3. Don't use personal information or common words as a password.

To change your ProjectWise password from within the ProjectWise Explorer client, first login to DOTWise. When in the system, go under the Tools menu and select Options.



Tools > Options

On the following panel, you will then need to enter your current password (1) along with your new password (2) and your new password a second time (3) to confirm.



Changing Your Password


3.4 INDOT ProjectWise Basics

INDOT's ProjectWise system can be split into two major usage groups, those who are using it to share data, and those who are using it for CAD workspace delivery. For those in the latter group, please review the DOTWise documentation that can be found on the [Downloads & Information](#) page of the INDOT CAD Support Website. This documentation covers most aspects of the CAD workspace and how to interact with our workspace when using ProjectWise along with where to find and how to use data within the system.

The remainder of this section will cover the basics of how ProjectWise is structured and how to work with data you're given access to.

3.4-1 ProjectWise Folder Layout

INDOT's ProjectWise system has been configured for a large amount of flexibility around the District/Regional location of projects and their associated Designation Number. When entering ProjectWise, you'll see the folder tree similar to the following:



External User Folder Tree

Note that the folder tree shown above is representative of what an external user might see. It's possible that you may see more or less depending on the areas you collaborate with INDOT on.

For most users, the following folders will be shown:


- District Locations – These are folders for each districts project data to be stored. Underneath each of these folders are a list of Des Numbers that have been created and currently contain data.
- INDOT Workspace – This is where the INDOT CAD Managed Workspace resides.

- Resources – Plotting Files for ProjectWise Plot Organizer and Documentation can be found here.
- Template Documents – Seed files for various CAD products and other template documents can be found here.

Unless otherwise directed, all project data and work is done under a district location\Des Number folder. When participating as a consultant you will have your own folder structure under the Des Number which is discussed in the next section.

3.4.2 Consultant Folder Structure

Once created in ProjectWise, consultant project structures look similar to the following.



Consultant Project Structure

In the above example the only change that will exist is that “Company A” will be replaced by the name of the creating firm. For security purposes, consultants will be unable to see other consultant folders and internal INDOT data. However please be advised that INDOT personnel can read (not edit) the contents of all consultant folders.

Also, shown in the previous example is the “Shared” folder. This folder is intended for INDOT personnel to use when sharing documents with consultant users. Please be advised that as a consultant you cannot edit the contents of this folder or place documents within it, but can read and copy them to your standard folder structure.

3.4.3 ProjectWise Security

Logged in and with a folder of your own, you’re now in a position to start working with ProjectWise. This section will give a brief overview of the security model and the rights/restrictions that have been enabled on the ProjectWise Datasource.

The DOTWise ProjectWise Datasource adheres to a strict security model, providing inner discipline security as well as external security, while providing all INDOT users the ability to review other data as necessary. In addition to these security features, there are additional settings that are used administratively in order to provide rapid support and file restorations, should the need arise. These settings are as follows:

1. Although you can create projects with the Project Creator you cannot delete one. Please contact INDOTCADsupport@indot.in.gov if you do not have access to the Help Desk.

2. You can create sub-folders under your project you cannot delete one- Contact CAD support for deletion request.
3. Users will not have folder delete privileges; this will aid in CAD Support's ability to process restore requests (no guarantees).
4. Document delete privileges will be granted (you are responsible for your own data) if you need something restored that was deleted we will make an attempt (no guarantees).

4. CAD Support and Documentation Resources

As has been mentioned at various points in this document, there are a number of resources available to make working with INDOT CAD and ProjectWise successful. This section will cover a number of these resources and where to access them.

4.1 INDOT CAD Website

INDOT CAD currently maintains our own external website as part of the IN.gov web portal. To get to our site in particular, navigate to <http://www.in.gov/indot/3084.htm> in the browser of your choice. Alternatively, our site can be reached by going to <http://www.in.gov/indot> and navigating to Doing Business with INDOT > Other Business > CAD Support.

On our webpage, you can find a number of resources including:

- News and Information on our workspace and releases, along with system maintenance notifications such as ProjectWise outages, etc.
- [Downloads and Information](#) where you can find our workspace releases and their associated documentation.
- [ProjectWise Web Server](#) access and the required downloads for its usage.
- [Current Version](#) information on the Bentley software versions and other assorted applications in use at INDOT.
- Links to other CAD resources such as the Indiana Design Manual, sample style sheets, and other resources.

4.2 DOTWise

For those users who are using the INDOT CAD Workspace either externally or connected to our ProjectWise managed workspace, INDOT CAD Support publishes our DOTWise manual twice yearly (March and September). These releases coincide with our typical workspace release schedule and allow for us to publish a variety of changes and documentation updates on a regular schedule.

The DOTWise manual in particular is our major CAD workflow and usage document and covers a number of topics including:

- ProjectWise and MicroStation tools
- Working with InRoads and OpenRoads in ProjectWise
- Survey deliverable production
- Design plan production
- Workspace change logs
- Many other items!

Please keep in mind that INDOT is a ProjectWise integrated shop, and that the resources and procedures called out in this document are all written with ProjectWise usage in mind. Most of the procedures should be easily adjusted for non-ProjectWise usage, but if there are any questions about the content of this document, please don't hesitate to ask.

4.3 ProjectWise Documents Folder

In addition to our website resources, we also publish our documentation to our ProjectWise server for access through those means. Our documentation folder is available both internally and externally and can be found in ProjectWise under the Documents\Resources\Documentation folder location, or at the following ProjectWise link if you're using the ProjectWise Explorer Client: [Documentation](#)

4.4 Bentley User Community


Newly created during the Fall of 2016, INDOT has partnered with Bentley to have a hosted Bentley Communities site. To use this site, you must have an active Bentley Communities account, and request access to our community. Instructions for doing so can be found at http://www.in.gov/indot/files/INDOT_Communities.pdf.

The purpose of the communities' site is to share ideas, have discussions, make suggestions, and network amongst likeminded individuals. Please join our community to contribute to the discussion!

4.5 Signing up for Gov Delivery and CAD Emails

In order to keep our customers informed of upcoming workspace releases, scheduled maintenance, and outages; CAD Support operates a listserv to provide this information in a timely fashion to all our users. In order to sign up for the listserv:

- If you are an INDOT employee and user of CAD software and or a ProjectWise user, you will automatically be enrolled to receive our updates at the time of getting a new user account.
- External users should enroll through the Subscribe for Email Updates link on the left side of the CAD Website (<http://www.in.gov/indot/3084.htm>) under the Other Business link



resources from our workspace as they pertain to the [Versions](#) page. Questions regarding application of these resources to your various software vendors.

News & Updates

- 12/5/16 - The INDOT CAD SS4 Workspace has been updated with new bugs in display and configuration between the Downloads and Information page to the workspace.
- Now Available, INDOT CAD has released the SS4 workspace. The workspace is still undergoing changes as the content of the workspace will be updated as the content of the workspace will be updated as the content of the workspace will be updated.
- Join Indiana DOT and Consultants Bentley

CAD Links

- [Map Insert Page for Title Sheets](#)

Sign Up for the CAD Listserv

4.6 Contacting INDOT CAD Support

The easiest way to contact INDOT CAD Support is normally through the Helpdesk Assistant. Tickets normally make their way to us relatively quickly and a response should be received shortly after submission. Should you feel that your ticket has not been responded to in a timely fashion, please

contact the members of the CAD Support team by forwarding your ticket to indotcadsupport@indot.in.gov so we can see if it's been assigned incorrectly. Please keep in mind however, that our SLA is 1 business day and not all issues can be addressed immediately.

For those instances where no ticket has been submitted, the same email address may be used to contact our staff by both internal and external users.